



#113 • 42" Removable Changing Station

Fits item #106 or #115



#108 • 50" Removable Changing Station

Fits items #105 or #107




#117 • 50" Removable Changing Station

Fits item #105 or #107



#109 • Hutch Top

Fits item #105 or #107
50 $\frac{1}{4}$ " x 14"d x 42 $\frac{3}{4}$ "h



#116SH • Hutch Top with Base

Fits item #105 or #107
Available in all styles
50 $\frac{1}{4}$ " x 14"d x 46 $\frac{3}{4}$ "h

Base is removable to
convert from bookcase
to hutch top



#114 • Mirror

39"w x 40 $\frac{1}{2}$ "h