

Shaker



MS-53731-C

Shaker Cornwall TV Stand

53"W x 23"D x 31"H

Wall Space: 37 3/4"

Side Openings: 11 1/2"W x 22"H

Center Openings: 25"W x 22"h

Wood: QSWO

Stain: OCS-113 Michael's Cherry

Hardware: Allison Flat Black, Knob 53005-FB

Features:

- Beveled Glass
- Two Adjustable Shelves Behind Center
- One Adjustable Shelf in Side Doors
- Made for Corner or Flat Wall



SH-55730-C

Shaker Corner TV Stand

55"W x 20"D x 31"H

Wall Space: 39 1/2"

Openings: 15 3/4"W x 20"H

Wood: Oak

Stain: OCS-113 Michael's Cherry

Hardware: Wood Knobs

Features:

- Beveled Glass
- Two Adjustable Shelves Behind Center
- One Adjustable Shelf in Side Doors
- Concave Top on Three Sides

Traditional



TR-48731-C

Traditional Corner TV Stand

48"W x 24"D x 31"H

Wall Space: 34"

Side Door Openings: 11"W x 21 1/2"H

Center Opening: 17 1/2"W x 21 1/2"H

Wood: Oak

Stain: OCS-102 Fruitwood

Hardware: Advantage Antique English, Knob K107-AEM

Features:

- Beveled Glass
- Two Adjustable Shelves in Center
- One Adjustable Shelf in Side Doors