



SH-7030

Shaker TV Stand

70"W x 20"D x 30"H

Side Door Opening: 14 7/8"W x 16 1/4"D x 14"H

Center Door Opening: 31 1/4"W x 16 1/4"D x 14"H

Wood: Brown Maple

Stain: OCS-228 Rich Tobacco

Hardware: Allison Flat Black, Knob 53005-FB

Features:

- Arched Top
- Flat Glass Doors
- One Adjustable Shelf Behind Each Wood Door
- One Adjustable Shelf Behind Set of Glass Doors
- Dovetailed Drawers
- Full Extension Drawer Slides
- Two Dividers in Top
- Two Dividers in Drawers

TRADITIONAL



TR-5030

Traditional TV Stand

50"W x 18"D x 30"H

Side Door Openings: 10 1/2"W x 15 1/4"D x 21 1/2"H

Center Door Openings: 17 1/2"W x 15 1/4"D x 21 1/2"H

Wood: Red Oak

Stain: OCS-104 Seely

Hardware: Advantage Antique English, Knob K107-AEM

Features:

- Two Adjustable Shelves Behind Each Door
- Beveled Glass Door
- Two Dividers



TR-5033

Traditional TV Stand

50"W x 18"D x 33 1/2"H

Side Door Openings: 8 3/4"W x 15 1/4"D x 24 1/2"H

Center Door Openings: 21"W x 15 1/4"D x 18 1/2"H

Sound Bar Opening: 21"W x 15 1/4"D x 4 1/2"H

Wood: Red Oak

Stain: OCS-104 Seely

Hardware: Advantage Antique English, Knob K107-AEM

Features:

- Two Adjustable Shelves Behind Each Wood Door
- One Adjustable Shelf Behind Center Door
- Beveled Glass Door
- Two Dividers