

MODERN SHAKER

**MS-4025**

Modern Shaker TV Stand

40"W x 18"D x 25"H

Door Opening: 34"W x 16"D x 17"H

Wood: QSWO

Stain: OCS-113 Michael's Cherry

Hardware: Allison Flat Black, Knob 53005-FB

Features:

- Flat Glass
- Two Adjustable Shelves Behind Doors

**MS-5025**

Modern Shaker TV Stand

50"W x 18"D x 25"H

Door Opening: 44"W x 16"D x 17"H

Wood: Rustic Cherry

Stain: OCS-107 Washington Cherry

Hardware: Allison Flat Black, Knob 53005-FB

Features:

- Flat Glass
- Two Adjustable Shelves Behind Doors

**MS-5030**

Modern Shaker TV Stand on Casters

50"W x 18"D x 30"H

Side Door Openings: 11 1/4"W x 16"D x 22 1/2"H

Center Door Opening: 18 1/2"W x 16"D x 22 1/2"H

Wood: Rustic Cherry

Stain: OCS-113 Michael's Cherry

Hardware: Allison Flat Black, Knob 53005-FB

Features:

- Flat Glass
- Two Adjustable Shelves Behind Each Door
- Two Dividers