

DINING ROOM



Side

Panel Back Chair
B-26-A • Arm • 20x18x37
B-26 • Side • 18x18x37



Side

Stick Back Chair
B-27-A • Arm • 20x18x34
B-27 • Side • 18x18x34



Side

Wagon Wheel Chair
B-271-A • Arm • 20x18x40
B-271 • Side • 18x18x40



Side

Low Back Chair
B-F1014-A • Arm • 18x19x40
B-F1014 • Side • 18x19x40



Side

Medium Back Chair
B-F1014-A-M • Arm • 18x19x44
B-F1014-M • Side • 18x19x44



Side

High Back Chair
B-F1014-A-H • Arm • 18x19x48
B-F1014-H • Side • 18x19x48



Western Chair
B-F1047 • 18x18x40



Contour Chair
B-25-A • Arm • 19x19x42
B-25 • Side • 19x19x42



Stick Back Chairs
BF-1010 • 18x20x40